



Features

- Dual-Core ST STM32H747XI
- Wide power input range (24 ~ 48 V_{DC})
- Wide operating temperature range (-40 ~ 85 °C)
- Ruggedized DIN-rail kit
- Ethernet communication (XIP, Modbus TCP)
- FIPWAY communication (UNI-TE point-to-point messaging)

Introduction

FIPBOX-H7/M2 hardware is designed for the maintenance and the retrofitting of older industrial installations based on the FIP/WORLDFIP fieldbus. Designed to be robust, this device is suitable for use in harsh environments. This two-module (M2) format is ideal for establishing an industrial FIP to Ethernet gateway.

FIPWAY-GW embedded software is a gateway service that allows you to connect any control system supporting Modbus TCP/IP or XIP (X-WAY over TCP/IP) to any FIPWAY device with a point-to-point connection using UNI-TE messages exchanges. This gateway is primarily designed to communicate with Schneider Electric's TSX Series 7 controllers: TSX 17, TSX 37 (Micro) and TSX 57 (Premium). An intuitive web-based user interface allows for easy configuration.

Specifications

General

- Certification CE, ready for EN 50155
- Dimension (W x D x H) 71 x 125 x 153 mm (2.8 x 5 x 6 in)
- Form Factor Small
- Enclosure Stainless Steel housing (SUS430)
- Mounting DIN-rail (EN 50022 standard) or Rubber Feet
- Weight (Net) 1.125 kg (2.48 lb)
- Power Requirement 24 ~ 48 V_{DC}
- Power Consumption 1.5W (typical), 6W (max.)
- Current Consumption 60mA @ 24V_{DC} (1.5W)
40mA @ 48V_{DC} (1.9W)

System Hardware

- Microcontroller STM32H747XI dual Cortex®-M7 + M4 32bit low power Arm® MCU
- Program Memory 1 MB (RAM)
2 MB (Flash)
- Storage 16MB (QSPI NOR Flash)
- RTC 1F Supercapacitor
- Security ATECC608B Crypto (Microchip)
- LED Indicators
 - H7 module
 - 1 x Power LED
 - 2 x Programmable LED (RUN / ERR)
 - 2 x LAN (Active, Status)
 - FIP module
 - 1 x Power LED
 - 1 x COM LED (Carrier detect)
 - 1 x ERR LED (Watchdog, TX error)

I/O

- Isolated FIP Port
 - 1x D-SUB 9 Male
 - ±30kV HBM
 - ±16kV IEC 61000-4-2 Contact discharge
 - ±4kV IEC 61000-4-4 Electrical fast transient
- LAN 1x 10/100 Mbps (RJ45)
- USB 1x USB-C (Programming / Flashing)
- Push Buttons
 - 1x Reset button
 - 1x User button (Boot mode)
- Power Connector 1x 4-pin terminal block (5.08 Phoenix plug)

Environment

- Operating Temperature -40 ~ 85 °C / -40 ~ 185 °F
- Relative Humidity 95% RH @ 40 °C / 104 °F, non-condensing
- Ingress Protection IP20

Ordering Information

- Product Range FIPBOX-H7/M2
- Product ID 700-500
- Origin Country France

FIPWAY-GW Characteristics

Service Description

This service is designed for the modernization and renovation of industrial systems based on FIPWAY industrial network. By converting XIP or Modbus TCP ethernet requests to FIPWAY UNI-TE requests, this gateway enables continued communication with older-generation controllers (TSX 7 series) while adding new-generation equipment.

FIP Features

- | | |
|---------------------|---------------------------|
| • Protocol | FIPWAY |
| • FIP Mode | Master / Slave |
| • FIP Baud Rate | 1 Mbps |
| • Medium Redundancy | None (Mono-medium) |
| • Messaging Service | UNI-TE requests/responses |


Ethernet Features

- | | |
|----------------------|--------------------------------|
| • Protocol | Modbus TCP or XIP |
| • Max. Connection | 5 |
| • Connection Timeout | Until 30 seconds (0: Disabled) |

Web Server


- | | |
|----------------------|--|
| • Authentication | Admin / User accounts |
| • Dashboard | Gateway transactions statistics,
Hardware / Software informations, Uptime,
Date & Time, Temperature |
| • Settings | Ethernet configuration (DHCP / Static IP),
Date & Time (Manually or SNTP server),
Gateway protocol (XIP or Modbus TCP) |
| • File Import/Export | Gateway configuration via JSON file |
| • Event Log | Info / Warning / Events / Errors logs |
| • FIP Presence Table | Display the presence of FIP Nodes |

Functional Diagram



Front I/O

1	H7 LEDs Status
2	FIP LEDs Status
3	USB-C Connector (Flashing / Programming) ⁽¹⁾
4	User Button (Boot modes selection)
5	Reset Button
6	RJ45 Ethernet Interface (WebUI access)
7	D-SUB9 Male FIP Interface
8	Power Supply Connector, Relay



Boot Modes

Mode	Buttons Seq.	Description
Normal Boot	1 RST=1	Press and release RST button to restart the device.
	2 RST=0	
Default Factory Boot	1 RST=1	Press and release RST button. Then press USR button within one second after releasing RST button to start the gateway with the default settings.
	2 RST=0	
	3 USR=1	
	4 USR=0	
Firmware Upgrade Boot ⁽²⁾	1 RST=1	Press the RST and USR buttons simultaneously. Then release the RST button, followed by the USR button.
	2 USR=1	
	3 RST=0	
	4 USR=0	

H7 LEDs Status

LED	Color	Indication
PWR	Green	Power OK
	Off	No power
RUN	Green	Service is active
	Green flashing	Factory boot (Default settings)
	Off	Service is inactive, or error
ERR	Red	Major unrecoverable fault
	Red flashing	Service is inactive
	Off	No error


⁽¹⁾ : It is not recommended to use USB-C for power supply. Application stability issues may occur. Use the 24~48V connector instead.

⁽²⁾ : This mode is used for Device Firmware Upgrade [DFU]. Connect USB-C to host machine to flash a new firmware using STM32CubeProgrammer utility.

FIP LEDs Status

LED	Color	Indication
PWR	Green	Power OK
	Off	No power
COM	Blue	Bus activity. Node is slave.
	White	Bus activity. Node is master.
	Off	No bus activity
ERR	Red	COM error (TX error or Watchdog)
	Off	No error

FIP Connector



Pin	Signal	Pin	Signal
Housing	Shield	Others	Not connected
6	A (D+)		
7	B (D-)		

Dimensions

